



STEPS TO REPLACE THE BULB in PIL 1000 or PIL 1000G

Tool kit provided with the unit has all the necessary tools for the operation below

STEPS:

- 1) Put the PIL unit on a high table for ease of access
- 2) Loosen the balloon cloth (if folded) so that the top portion of the cage can slide out
- 3) Unscrew the outer 6 screws **only** of the top metal plate
- 4) Align the notch where the wire can slide out and slowly guide the wire cage out
- 5) Snap the bottom flap open (bottom of the cage) and slide your hand in the cage
- 6) Unscrew the bulb slowly and take it out of the cage
- 7) Screw a new bulb in the holder and tighten it
- 8) Snap the flap back on at the bottom of the cage
- 9) Guide the cage and the wire through the notch and slide the cage all the way in the balloon
- 10) Tighten the outer 6 screws for a snug fit
- 11) Turn the unit on, blowers on and the bulb on to ensure that the bulb is working

NOTE:

If you have any questions, please email us at service@prismlighting.net or feel free to call us at 904-880-9900

