



Installation of new complete balloon cloth on Prism Inflatable Lighting System

*Tool kit provided with the unit has all the necessary tools for the operation below
Only a licensed electrician should operate on the PIL*

Spares – Complete balloon cloth with bulb cage, wiring, bulb etc.

1. Unfold the balloon cloth and lay it out neatly near the base of the PIL
2. Please see that the circlip is around the fiber cover
3. Unscrew the cap of the cable guide on top of the fiber cover
4. Take the inner lamp wiring (three wires) in the sleeve and slide it through the cap first and then the cable guide. Tighten the cap
5. Slide the balloon cloth on top of the fiber cover and tighten the circlip around it (use the screw driver in the tool kit)
6. Open the small screws of the wire connector at the base and connect the three wires in the connector (*opposite to the three wires for the lamp that are going inside the Control Gear box*) and tighten the screws
7. Test the connections and turn the system on

Please call Prism Lighting Services LLC for any further questions at 904-880-9900 or email service@prismlighting.net