

Prism Inflatable Lighting Tower – Retrofit Kit for installing Stabilizing poles with the holding tube on older PIL 1000 (G) units.

Stainless Steel Stabilizing poles with the inner and outer holding tubes –



A) Outer holding tube needs to be welded to the frame of the unit (opposite to the CG box) – after removing fiber cover and all the other parts that can interfere with welding process –



- B) Inner holding tube needs to be screwed on to the fiber cover after you drill a hole in the SS frame and thread it for one of the sides



- C) After connecting the poles from 1 – 6 (they are marked at the base), connect one end (clip) of pole 1 to the eyelet of the flap of the balloon cloth and the other end to be slid in the holding tube and make sure it is a snug fit

